

- > Port size: Ø 4 ... 12 mm
- > High flow performance



Technical features Medium:

Compressed air Operating pressure: 0,2 ... 10 bar (2 ... 145 psi) **Tube sizes:** 4 ... 12 mm **Tubing types:** PA 11 or 12 PU 85, 95 or 98 durometer

Ambient/Media temperature:

6mm-

 $0^{\circ}C \dots +60^{\circ}C (+32 \dots 140^{\circ}F)$ Air supply must be dry enough to avoid ice formation at temperatures below +2°C (+35°F)

Materials:

Body: PBT, tube ø 10 & 12 mm aluminium Seals: NBR u-packing and O-rings Release sleeve and backing ring: POM Grab-ring: stainless steel Collar: ZNDC

Options selector

C00GL**00

>	O/D tube size	Substitute
	4	04
	6	06
	8	08
	10	10
	12	12

Method of assembly



- 1. Ensure that the end of the tube is cut square and is free from burrs.

2. Push the tube through the collet

into the fitting.

- Continue pushing the tube through the 'O'-ring until it bottoms on the tube stop then pull back.



4. To disconnect push the tube into the fitting, hold down the collet and withdraw the tube.

Components



- 1 Impact resistant PBT body in black
- 2 Release buttons are red for metric, grey for inch
- Stainless steel grab ring with special design to retain softer tube and provide easy releasability.
- Silicon free U-packing provides leak tight tube seal under side loading.





Technical data

	1	T	
٥A			ž

ØA	ØК	T*1)	
4	10,5	15	
6	12,5	16,5	
8	14,5	18,5	
10	17,5	20	
12	20,5	23	

*1) Dimensions here and in the individual tables refer to the collet being in the 'IN' position.

In-line non-return valve (PBT) C00GL





ØA	С	Model
4	42	C00GL0400
6	47,5	C00GL0600
8	55,5	C00GL0800



ØA	С	Model
10	65	C00GL1000
12	73	C00GL1200

Warning

These products are intended for use in industrial compressed air systems only. Do not use these products where pressures and temperatures can exceed those listed under

»Technical features/data«.

Before using these products with fluids other than those specified, for non-industrial applications, life-support systems or other applications not within published specifications, consult IMI NORGREN.

Through misuse, age, or malfunction, components used in fluid power systems can fail in various modes.

The system designer is warned to consider the failure modes of all component parts used in fluid power systems and to provide adequate safeguards to prevent personal injury or damage to equipment in the event of such failure.

System designers must provide a warning to end users in the system instructional manual if protection against a failure mode cannot be adequately provided.

System designers and end users are cautioned to review specific warnings found in instruction sheets packed and shipped with these products.

FITTINGS

Permit free flow of air in one direction only Simple, reliable design Silicone free Low cracking pressure

T56 male connections have an O-ring in parallel threads

1 --- ⊘₩₩--- 2

Technical data Medium:

Compressed air, filtered, lubricated and non-lubricated **Operating pressure:** 1.5 to 145 psig (0.1 to 10 bar) **Operating temperature:** 0°F to 175°F* (-20°C to +80°C) *Consult our Technical Service for use below 35°F (+2°C)

Materials

Body: aluminum (T55), brass (T56) O-ring: nitrile rubber Valve: POM Spring: stainless steel Note: FPM seals for high temperature version

T55 Series

Port	Flow Factor	Cracking	Weight	Model	
Size	Cv**	pressure	0Z	NPT	BSPP
1/8	0.59	0.73	0.53	T55A1800	T55C1800
1/4	1.35	0.73	0.88	T55A2800	T55C2800
3/8	2.20	0.73	2.12	T55A3800	T55C3800
1/2	3.70	0.73	2.82	T55A4800	T55C4800

** Cv measured in US gal/min.



Model	Α	В	C	D	E	F	G	Н
T55A1800	0.55	1.67	1/8	-	0.28	0.54	0.16	0.59
T55C1800	0.55	1.67	1/8	0.28	0.28	0.54	0.16	0.59
T55A2800	0.67	2.13	1/4	-	0.31	0.66	0.20	0.73
T55C2800	0.67	2.13	1/4	0.41	0.31	0.66	0.20	0.73
T55A3800	0.94	2.48	3/8	-	0.35	0.93	0.28	1.02
T55C3800	0.94	2.48	3/8	0.47	0.35	0.93	0.28	1.02
T55A4800	1.06	3.03	1/2	-	0.47	1.05	0.39	1.18
T55C4800	1.06	3.03	1/2	0.59	0.47	1.05	0.39	1.18

T56 Series					
Port	Flow Factor	Cracking	Weight		
Size	Cv**	pressure	0Z	NPT	BSPP
1/8	0.59	0.73	1.59	T56A1800	T56C1800
1/4	1.23	0.73	2.82	T56A2800	T56C2800

** Cv measured in US gal/min.









- > Port size: G1/4 ... G1 1/2
- Assists in complying with safety regulations
- > Tamper proof
- > Compact and safe design
- > Low pressure drop.
- Automatically resets after failure correction
- > High corrosion resistance
- High air pressure rating



Technical features

Medium:

Compressed air, filtered, lubricated and non-lubricated, inert gases **Operation:** Fixed uni-directional excess flow

automatic shut off valve.

Operating pressure: 16 bar max. (232 psi) Minimum according to hose length. Drop pressure at shut-off flow . 0,14 or 0,3 bar (2 or 4 psi) Port size:

installation

G1/4, G3/8, G1/2, G3/4, G1, G1 1/2 **Mounting:** In-line two ways valve To be inserted between fixed air supply and flexible hose air line See guidelines for typical

Ambient/Media temperature:

-20 ... +80°C max. (-4 ... +176°F) Air supply must be dry enough to avoid ice formation at temperatures below +2°C (+35°F) Materials:

Body: Aluminium Internal parts: Brass Spring: Stainless steel

Technical data, standard models

Function	Port size	Drop pressure at shut off flow (bar)	Shut off flow rate at 7 bar (dm³/s) ±10%	Flow at 7 bar Δ p 0,07 bar (dm³/s)	Weight (kg)	Model
	G1/4	0,14	8,3	6,5	0,041	T60C2890
	G1/4	0,3	14	6,5	0,041	T60C2891
	G3/8	0,14	19,4	13,5	0,065	T60C3890
	G3/8	0,3	32,2	13,5	0,065	T60C3891
	G1/2	0,14	32,2	23,2	0,150	T60C4890
1 (144) 2	G1/2	0,3	48,3	23,2	0,150	T60C4891
	G3/4	0,14	48,3	43	0,130	T60C6890
	G3/4	0,3	80	43	0,130	T60C6891
	G1	0,14	92	68	0,540	T60C8890
	G1	0,3	128	68	0,540	T60C8891
	G1 1/2	0,14	186	145	1,1	T60CB890
	G1 1/2	0,3	268	145	1,1	T60CB891

Flow and pressure test conducted according to ISO 6358 test circuit. Mean measured flow values are provided at standard reference conditions.

Options selector

Thread	Substitute
ISO G, parallel	С
NPT	Α

T60*****

└── ─	Flow range	Substitute
	0,14	90
	0,3	91
	Port size	Substitute
	1/4"	28
	3/8"	38
	1/2"	48
	3/4"	68
	1"	88
	1 1/2"	B8





Minimum pressure required to shut off the air supply - check failure flow conditions

Hose length vs minimum pressure supply (1/4" ... 3/8")

Hose length vs minimum pressure supply (1/2" ... 3/4")

Hose length vs minimum pressure supply (1" ... 1 1/2")



Flow required to shut off air supply - check normal flow conditions

Flow (±10%) vs pressure supply (1/4 ... 1/2")

Flow (±10%) vs pressure supply (3/4 ... 11/2")



Measurements

Flow and pressure tests conducted according to ISO-6358 test circuit. Mean measured flow values are provided at standard reference condition (20° C, 1,01 bar).

Indicated pressure values are relative pressure in bar.



Hose lengths

Graphs are for indicated hose internal diameter in key. Consult our Technical Service for hose lengths and internal diameters different from the recommended one.



Guidelines for typical installation

The Air Fuse should be installed directly between fixed or rigid pipework and the flexible tube to protect the whole length of the flexible tube. Only tubing after the Air Fuse is protected. The Air Fuse must be installed in the correct direction for Airflow. Failure to do this will render the Air Fuse ineffective. When a shut off valve is located before the Air Fuse, the valve must be opened slowly in order to control initial air flow and avoid decompression effects which may trip the Air Fuse.



How to select an air fuse

- a) The Port size of the Air Fuse should be nominally equal to that of the supply lines - eg a 1/2" (12.7mm) Air Fuse should be used with a 1/2" (12.7mm) ID hose.
- b) Always select the high flow model (91) if there is sufficient system pressure for the length of hose to be protected.
- See tables hose length vs minimum supply pressure.
- c) If there is insufficient system pressure, or long hose lengths are to be protected, use model 90.
- d) After installation always test each valve for proper function. See section how to check an Air Fuse below.
- e) The pneumatic system must be capable of delivering the flow required to activate the Air Fuse.
- f) For use with spring coils consult table. See table flow vs pressure supply.

How to check an air fuse

- * Install Air Fuse following the instructions supplied
- * Connect tool or complete circuit to the air line
- * Switch on operation to ensure a complete cycle is performed * If tool or complete circuit starts and runs satisfactorily, stop operation and drain air line. Disconnect hose from tool or circuit and secure hose end. Turn on air supply progressively (to avoid decompression effect). Prior to fully reaching operation conditions, the valve should suddenly activate and cut off the flow. A slight air flow will remain as part of the

automatic re-set function. If the Air fuse is not activated the unit should

be disconnected and the lower flow range Air Fuse should be used.

Spring coils and air fuse minimum required pressure (bar)

	5
$\begin{array}{c c c c c c c c c c c c c c c c c c c $	
1,02,54,8PA331003281,23,36,4PA331004281,54,2PA331005282,26,2PA331008284,4PA33100528PA331005280,70,91,54,10,71,02,05,40,71,32,4PA3312003880,71,93,7PA331206381,43,8PA3312015380,70,90,71,51,50,70,90,72,12,14,6PA331500488	
1,23,36,4PA3310004281,54,2PA331005282,26,2PA331005284,4PA331005280,70,91,54,1PA3312003380,71,02,05,4PA3312004380,71,32,40,71,93,71,43,80,70,90,71,51,53,50,70,90,71,32,12,4PA3312003881,43,80,70,90,71,51,53,50,70,90,72,12,14,6PA331500448	
1,54,2PA3310005282,26,2PA331008284,4PA3310015280,70,91,54,1PA3312003880,71,02,05,4PA3312004380,71,32,40,71,93,71,43,80,70,90,71,51,53,50,70,90,71,51,53,50,70,90,71,51,54,60,70,90,71,52,14,6	
2,2 6,2 PA331000828 4,4 PA331001528 0,7 0,9 1,5 4,1 PA331200388 0,7 1,0 2,0 5,4 PA331200438 0,7 1,3 2,4 PA331200538 0,7 1,9 3,7 PA331200538 1,4 3,8 PA331201538 0,7 0,9 0,7 1,5 1,5 0,7 0,9 0,7 1,5 4,6	
4,4 PA331001528 0,7 0,9 1,5 4,1 PA331200338 0,7 1,0 2,0 5,4 PA331200438 0,7 1,3 2,4 PA331200538 0,7 1,9 3,7 PA331200538 1,4 3,8 PA331201538 0,7 0,9 0,7 1,5 1,5 3,5 PA331500348 0,7 0,9 0,7 2,1 2,1 4,6 PA331500448	
0,7 0,9 1,5 4,1 PA331200338 0,7 1,0 2,0 5,4 PA331200438 0,7 1,3 2,4 PA331200538 0,7 1,9 3,7 PA331200838 1,4 3,8 PA331201538 0,7 0,9 0,7 1,5 1,5 3,5 PA331500488 0,7 0,9 0,7 2,1 2,1 4,6 PA331500448	
0,71,02,05,4PA3312004380,71,32,4PA3312005380,71,93,7PA3312005381,43,8PA3312015380,70,90,71,51,50,70,90,72,12,14,60,70,90,72,12,14,6	
0,71,32,4PA3312005380,71,93,7PA3312015381,43,8PA3312015380,70,90,71,51,50,70,90,72,12,14,6PA331500448	
0,71,93,7PA3312008381,43,8PA3312015380,70,90,71,51,53,50,70,90,72,12,14,6	
1,4 3,8 PA331201538 0,7 0,9 0,7 1,5 1,5 3,5 PA331500348 0,7 0,9 0,7 2,1 2,1 4,6 PA331500448	
0,7 0,9 0,7 1,5 1,5 3,5 PA331500348 0,7 0,9 0,7 2,1 2,1 4,6 PA331500448	
0,7 0,9 0,7 2,1 2,1 4,6 PA331500448	
0,7 0,9 0,9 2,6 2,6 5,8 PA331500548	
0,7 0,9 1,4 3,8 3,8 PA331500848	
5,4 PU310800228	
1,3 3,8 PU311000228	
2,7 PU311000428	
5,0 PU311000628	
6,0 PU311000828	
0,7 1,2 2,4 6,6 PU311200238	
0,9 2,5 4,8 PU311200438	
1,3 3,7 PU311200638	
1,6 4,6 PU311200838	

Note: Only the spring coils in these table can be protected by the air fuse!



Dimensions





С	ØD	E	G) _	Model
51	20,5	3	11 (10)	21	T60C289
62	24	5	14 (10,3)	24	T60C389
78	32	5	15 (13.6)	32	T60C489
90	32	5	19 (14,1)	32	T60C689
118	51	5	25,5 (16,8)	51	T60C889
145	63,5	5	25,5 (17,3)	64	T60CB89
	C 51 62 78 90 118 145	C Ø D 51 20,5 62 24 78 32 90 32 118 51 145 63,5	C Ø D E 51 20,5 3 62 24 5 78 32 5 90 32 5 118 51 5 145 63,5 5	C Ø D E G 51 20,5 3 11 (10) 62 24 5 14 (10,3) 78 32 5 15 (13.6) 90 32 5 19 (14,1) 118 51 5 25,5 (16,8) 145 63,5 5 25,5 (17,3)	C Ø D E G S 51 20,5 3 11 (10) 21 62 24 5 14 (10,3) 24 78 32 5 15 (13.6) 32 90 32 5 19 (14,1) 32 118 51 5 25,5 (16,8) 51 145 63,5 5 25,5 (17,3) 64

Values in () for NPT

Warning

These products are intended for use in industrial compressed air systems only. Do not use these products where pressures and temperatures can exceed those listed under

»Technical features/data«.

Before using these products with fluids other than those specified, for non-industrial applications, life-support systems or other applications not within published specifications, consult IMI NORGREN.

Through misuse, age, or malfunction, components used in fluid power systems can fail in various modes.

The system designer is warned to consider the failure modes of all component parts used in fluid power systems and to provide adequate safeguards to prevent personal injury or damage to equipment in the event of such failure.

System designers must provide a warning to end users in the system instructional manual if protection against a failure mode cannot be adequately provided.

System designers and end users are cautioned to review specific warnings found in instruction sheets packed and shipped with these products.